

RHK	511276			
RBM	PRPVC901CIP			
FTY	Q1DP-900N2			
序号	名称	Spare Parts list	数量	
Pos.	Description CN	Description EN	Qty	
1	插头及电缆	mains cable and plug	1	
2	浮子开关及电缆	Float switch	1	
3	手柄盖	handle cover	1	
4	自攻螺钉	screws	2	
5	手柄体	handle	1	
6	后泵壳	rear pump casting	1	
7	电缆护套	cable jacket	2	
8	电缆压扣	cable compaction buckle	2	
9	电容	capacity	1	
10	电缆压块	cable compaction board	1	
11	自攻螺钉	screws	3	
12	套筒	sleeve	1	
13	后盖	rear cover	1	
14	波形垫圈	corrugated gasket	1	
15	轴承	bearing	2	
16	转子	rotor	1	
17	定子	stator	1	
18	前衬	front cover	1	
19	O形密封圈	oil seal	1	
20	前盖	front lining	1	
21	骨架油封	skeleton seal	2	
22	机械密封	ceramics seal	1	
23	叶轮	impeller	1	
24	O形密封圈	oil seal	1	
25	自攻螺钉	screws	4	
26	主泵壳	main pump housing	1	
27	钢球	steel ball	1	
28	垫圈	washer	1	
29	O形密封圈	oil seal	1	
30	底座	base	1	
31	自攻螺钉	screws	4	

32	底板	base plate	1		
33	自攻螺钉	screws	2		



